# SECTION 8


### **AIR CONDITIONING**

• Automatic air conditioning controls

304

### Automatic air conditioning controls

Operations such as changing the air outlets or fan speed are carried out on the screen. To display the air conditioning control screen, push the "**MENU**" button and select "**Climate**".



	(In degrees Fahrenheit or Centigrade)
2	Outside temperature display (In degrees Fahrenheit or Centigrade)
3	"DUAL" (Temperature setting mode change button)
4	Air flow control buttons 308
5	Passenger side temperature dis- play (In degrees Fahrenheit or Centi- grade)

1 Driver side temperature display

	The state of the s
6	Fan speed control buttons
	307
7	Windshield wiper de-icer button
	312
8	<b>"A/C"</b> 310
9	Air intake control button
	307, 309
10	Rear window defogger button
	313
11	Windshield air flow button
	310
12	"AUTO" button 306

#### 13 "PASSENGER TEMP" buttons

(Passenger side temperature control button)

#### 14 "TEMP" buttons

(Driver side temperature control button) (At the independent mode that display shows "DUAL"; mainly for driver and secondarily for front passenger)

(At the linked mode that display does not show "**DUAL**"; for driver)

..... 306, 308

#### (a) Climate control

Air outlets and fan speed are automatically adjusted according to the temperature setting.

The "POWER" <"ENGINE START STOP"> switch must be in ON <IGNITION ON> mode.



Push the "MENU" button and select "Climate" to display the air conditioning control screen.

#### **NOTICE**

To prevent the 12-volt battery from being discharged, do not leave the air conditioning on longer than necessary when the hybrid system is off <the engine is not running>.

#### **INFORMATION**

- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
  - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
  - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic operation mode.



By pushing the switch above, you can operate the voice command system.

For the operation of the voice command system and the command, see pages 49 and 54.

- (b) Using automatic air conditioning system
- Switching to automatic operation mode




Push the "AUTO" button.


The air conditioning system begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

Push and hold " $\lor$  OFF" button to turn the air conditioning system off.

 Setting the vehicle interior temperature



Push the " $\wedge$ " button on "TEMP" to increase the temperature and " $\vee$ " to decrease the temperature.



"DUAL" is used to set the temperatures independently for the driver's seat and front passenger seat.

When the "**DUAL**" indicator is on, the temperature for the driver's seat and front passenger seat can be adjusted separately.

 Switching the air intake control to automatic mode



Push the air intake control button to switch to automatic mode.

The air conditioning system automatically switches between outside air and recirculated air modes.

#### **INFORMATION**

You can adjust the setting in automatic mode. (See page 414.)


- (c) Adjusting the settings manually
- Setting the fan speed



To turn on the air conditioning system and adjust the fan speed, push the " $\wedge$ " button on fan speed control button to increase the fan speed and push the " $\vee$  OFF" button to decrease the fan speed.


To turn the fan off, push and hold the " $\lor$  OFF" button.

#### Using the screen-



- 1 Fan speed at low
- 2 Fan speed at high

### Setting the vehicle interior temperature



To adjust the temperature setting, push the " $\wedge$ " button on "TEMP" to increase the temperature and push the " $\vee$ " button to decrease the temperature.

When the "DUAL" indicator is on, the temperature for the driver's seat and front passenger seat can be adjusted separately.


#### • Switching the air outlets



To change the air outlets, push the "MODE" button.


The air outlets used are switched each time the button is pushed.

#### Using the screen—




- 1 Panel
- 2 Bi-level
- 3 Floor
- 4 Floor/windshield


The air flow shown on the display indicates the following.




► Air flows to the upper body (Panel)



► Air flows to the upper body and feet (Bi-level)



► Air flows to the feet (Floor)



► Air flows to the feet and the windshield defogger operates (Floor/windshield)

- Switching between outside air and recirculated air modes
- ► Type A



#### Push the air intake control button.

The mode switches between outside air mode (the indicator is off), "AUTO" mode and recirculated air mode (the indicator is on) each time the button is pushed.


#### ▶ Type B



Push the air intake control button.

The mode switches between recirculated air mode and outside air mode each time the button is pushed.

#### (d) Defogging the windshield



The air conditioning system operates automatically.


Recirculated air mode will automatically switch to outside air mode. It is not possible to return to recirculated air mode when the switch is on.

### **CAUTION**

To prevent the windshield from fogging up


Do not use the windshield air flow button during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

# (e) Adjusting the position of and opening and closing the air outlets




#### ► Front center outlets

- Direct air flow to the left or right, up or down
- 2 Turn the knob to open or close the vent



#### ► Front side outlets

- Direct air flow to the left or right, up or down
- 2 Turn the knob to open or close the vent



- Rear outlets
- Direct air flow to the left or right, up or down
- 2 Turn the knob to open or close the vent

#### **INFORMATION**

 Operation of the air conditioning system in Eco drive mode (vehicles with hybrid system)

In Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency:

- Engine speed and compressor operation controlled to restrict heating/cooling capacity
- Fan speed restricted when automatic mode is selected

To improve air conditioning performance, perform the following operations:

- Adjust the fan speed
- Turn off Eco drive mode
- Customization (vehicles with hybrid system)

The air conditioning control restriction of Eco drive mode can be changed to the same setting as that used in normal drive mode. For details, refer to the "Owner's Manual".

- Registering air conditioning settings to electronic keys
  - Unlocking the vehicle using an electronic key and turning the "POWER" <"ENGINE START STOP"> switch to ON <IGNITION ON> mode will recall that key's registered air conditioning settings.
  - When the "POWER" <"ENGINE START STOP"> switch is turned off, the current air conditioning settings will automatically be registered to the electronic key that was used to unlock the vehicle.

The system may not operate correctly if more than one electronic key is in the vicinity or if the smart access system with pushbutton start is used to unlock a passenger door.

Settings for the electronic key and the corresponding door can be changed. Contact your Lexus dealer.

• Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and ambient conditions. As a result, the following may occur:

- Immediately after the button is pushed, the fan may stop for a while until warm or cool air is ready to flow.
- Using the system in recirculated air mode

The windows will fog up more easily if recirculated air mode is used for an extended period.

Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting and the inside temperature.

• Window defogger feature

Recirculated air mode may automatically switch to outside air mode in situations where the windows need to be defogged.

 When outside air temperature is below 32°F (0°C)

The cooling and dehumidification function may not operate even when "A/C" is on.

 When the indicator light on "A/C" flashes

Select "A/C" to turn off the cooling and dehumidification function and turn it on again. There may be a problem in the air conditioning system if the indicator light continues to flash. Turn the air conditioning system off and have it inspected by your Lexus dealer.


 Automatic air intake change mode In automatic mode, the system automatically switches between recirculated air and outside air modes according to whether the system detects harmful substances such as exhaust gas in the air outside.

If you select automatic mode when only the fans are operating, the air conditioning system will turn on automatically.

# (f) Windshield wiper de-icer (if equipped)

This feature is used to prevent ice from building up on the windshield and wiper blades.

The windshield wiper de-icer can be operated when the "POWER" <"ENGINE START STOP"> switch is in ON <IGNITION ON> mode.



## Turns the windshield wiper de-icer on/off.

The windshield wiper de-icer will automatically turn off after approximately 15 minutes.

### **!** CAUTION

When the windshield wiper de-icer is

Do not touch the lower part of the windshield or the side of the front pillars, as the surfaces can become very hot and burn you.

# (g) Rear window and outside rear view mirror defogging



To turn the electric rear window and outside rear view mirror defogger on, push the button above.

The "POWER" <"ENGINE START STOP"> switch must be in ON <IGNITION ON> mode.

The thin heater wires on the inside of the rear window and the heater panels in the outside rear view mirrors will quickly clear the surface.

Keep your hands off the mirror faces when the system is on.

The indicator light is on when the defogger is operating.

### **↑** CAUTION

When the outside rear view mirror defoggers are on, do not touch the outside surface of the rear view mirror as it can become very hot and burn you. The defoggers will automatically turn off after 15 to 60 minutes. The operation time changes according to the ambient temperature and vehicle speed.


If further defrosting or defogging is desired, simply actuate the switch again. When the surface has cleared, push the button once again to turn the defogger off. Continuous use may cause the 12-volt battery to discharge, especially during stop-and-go driving. The defogger is not designed to dry rain water or to melt snow.

If the outside rear view mirrors are heavily coated with ice, use a spray de-icer before operating the system.

#### **NOTICE**

- When cleaning the inside of the rear window, be careful not to scratch or damage the heater wires or connectors.
- To prevent the 12-volt battery from being discharged, turn the switch off when the hybrid system is off <the engine is not running>.

#### (h) Outside temperature display



### Outside temperature is displayed on the screen.

The displayed temperature ranges from  $-40^{\circ}F$  ( $-40^{\circ}C$ ) up to  $122^{\circ}F$  ( $50^{\circ}C$ ).

If the temperature shows "- -" or "E", take your vehicle to your Lexus dealer.

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 15.5 mph [25 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)